

GENSET SERVICE SHEET

Service Inspection Item	ок	Fault Found
CHANGE		
Engine oil	1	
Engine oil filter	1	
Fuel filters	1	
Primary air filter	J	USED ORIGIN
CHECK	-	(NEW).
Engine oil level		
Coolant level	1	
Air Intake piping, Induction system for leaks and clamps for tightness	1	
Crankcase breather tube	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	
Charge air cooler	1	
Charge air piping	/	
Cooling system hoses for condition and clamps for tightness	/	
Air intake piping, hoses for general condition and chaffing	V /	
Fan cooling	-	
Drive belts	-	
Fan belt tensioner		
Cooling fan hub	- V	
Radiator and coolers for debris (wash if necessary)		Necos Mari
Engine mounts		NEEDS WASH
Fuel system for loose bolts and fittings		
Fuel leaks	- V	
Exhaust system for leaks and clamps for tightness	+ '	
Frame and attachment for cracks	-	
	-	
Battery leads for evidence of rubbing, scuffing, excess heat and deterioration	/	
Check battery	/	
Check alternator charging	1	
Check engine faults	1	F
Engine starting system		
Engine shutdown system		
Frame and attachment for cracks	/	
Operation of emergency stops		
Frame and attachment for cracks		
Accumulation of fuel, oil, grease etc that may cause a fire hazard	T Y	NEEDS WASH
.W		
	_	
		f.
ED OUT BY: CHECKED & RECORD	50 BV	

TL90 Lighting trailer



Trailer Service Inspection

Work Order number.		A SERVICE – Every 6 months B SERVICE – Every 12 months				
Unit N°: STR 241 00 3 Hub meter reading (if fitted)				Date: 16/12/2/4		
F	Park machine on stable, level group Place wheel chocks at both front a Place 'danger' and/or 'out of service' Isolate electrics on equipment (if file	WORK T: and and apply the part and rear wheels. tags in appropriate pla	(or persor services king brake	poxes below to ns) performing n. If item not fitt	mechanical a	nd lube
	_ELECTRICAL All lights for correct operation	To See 18/4		\$ 11 PM - 13	/	
	Breakaway battery condition indica				N/A	
	Earth to chassis and return from tra				N/A	N. 1
	Breakaway switch – pull pin and check proper function (if fitted) Label noting requirement of hauling unit to have acceptable charging and warning devices			1.14	RUSTY	
	(if required)	y unit to have accepta	able charging and wan	ning devices	NA	
	CHASSIS AND SUSPENSION					
	Wheel nuts for tightness and condi				\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	0.
	Wheel for cracks or damage Tow hitch for wear and loose bolts				//	RUST
	Safety chains and D shackles for c				//	
	Broken or flattened springs	orrect rating, conditio	n and damage		/	
С	Chassis or axle housing cracks	15			17	
Н	Worn, loose or rusted fasteners an	d shackle link wear			1	
Ε	700000 0000 H	o oncono min woai				
C	Hub seals for damage or leaks				1	
K	Ramp pivots (if fitted)				N/A	
K	Ramp bifold chains (if fitted)				N/A	
	Mudguards condition (if fitted)					MINOR
	Mudflaps (if fitted)				1	
	Access step (if fitted)				N/A	
	BRAKING SYSTEM					
	Braking function and performance					ADSUSTER
	Check proper adjustment and adjust	st as required			/	
	Hub and drum assemblies for scori	ng or wear				
	Brake assembly internal parts for w	- T	(if fitted)	2		
	Brake magnets for wear and replace		.,		1 2	
	Hydraulic brake system, change flu					
	Conduct road test to check effective	eness of braking syst	em			

Document Author: John Stonehouse

Version:

14/11/23

Page Number:

1/2



Trailer Service Inspection

					A B	COMME
	Jockey wheel the	nread (if fitted)				NEEDNE
"	S cam shafts (if fitted)					TA LLY III
LUBRICATE	Towing king pin (if fitted)					
	Spring hanger bushes (if fitted)					
5	All grease nippl	All grease nipples				
	REPACIL	WHEEL BEAD	RINGS	(4	(de	
TYRE		D CONDITION - Check			7 7 7 7 1	
Tyre Pressure		1 st Axle RHS	RHS 1 st Axie LHS 2 nd Axie RHS		2 nd Axle LHS	
	Actual	40P51	40 P51			
	Adjusted		2.56			
	Condition					
	% Worn	9020	904			
	Make	HIFLY	HIFLY			90
	Size	185 R14C	185R14C			
		SOCKEY W		Tu ced.		
Print	K CARRIED (AND RECORDED B		
Name Signed	d: 1	rch 2/24	Print Name: Signed: Date:	_ John Store _ JW Store 16/12/24	house	

Document Author:

John Stonehouse

Version:

14/11/23

Page Number:

2/2